

Swivel Banner Care and instructions

Vertical to Horizontal rotate 360° • Telescopic Height Adjustment • Tilt Function

If you need flexibility this is the perfect solution. You are able to install the banner, rotate tilt and telescope up in moments. The huge banner size will ensure your message is seen no matter what venue. The swivel and height adjustment makes this stand perfect for use with a table or as a substitute for expensive table top display

Banner care:

The banner should be loosely rolled with the image facing inside. Do not fold the banner (this will cause creases). The banner should be stored in the pouch or tube if supplied. Store in a cool dry place. Avoid direct sun and heating vents. Also avoid prolonged exposure to heat (car trunk, storage building etc.)

Clean lightly with water and/or mild detergent or hand soap. Dry thoroughly with a clean soft cloth. Do not use solvents.

PACKAGE CONTENTS



Banner Size

- 36" x 78"
- 36" x 62"
- 40" x 75"
- 48" x 72"

Weight
11 lb



Vertical to horizontal • Telescopic height & Tilt function Selection of many banner sizes

1

- Place the base plate on the floor.
- Insert the center bar into the base plate.
- Loose the middle joint to extend the center bar

2

Insert the short poles and the long poles into the center hub.

3

Hang the banner from the top to the bottom.

4

Rear bolt Front bolt

- Loose the front to rotate the banner.
- Loose the rear bolt to change the leaning angle.